```
Make a Call
Handset
                          Lift Handset + Internal Number
                          Lift Handset + 9 + External Number
                          L1 to L4 + External Number
Speaker
                          + Internal Number or + 9 + External Number
Headset
                          + Internal Number or + 9 + External Number
                          Internal Number + Dial or 9 + External Number + Dial
Predial
                          Phone Bk + Personal Addr Book +...
Directory
                          Menu + List of calls +...
Call Lists
Redial
                           REDIAL
Make a second Call
while on a call
                          HOLD + Internal Number or HOLD + 9 + External Number
                          During a second call press CONFERENCE
Conference
Answer a Call
Handset
                          Lift handset
                           or Answer
Speaker
Headset
                           or Answer
                           Answer or Options +... or L1 to L4
Answer Second Call
Handle a Call
Hold/Retrieve
                           HOLD
Transfer
                           HOLD + Number + Hangup
Park/Unpark
                           PARK
                             L1 to L4
Switch between Calls
Forward
Forward All Calls/ Clear Forward
                               FORWARD
                                Menu + Call Forward + Forward on busy
Forward on busy
                                Menu + Call Forward + Forward no Answer
Forward No Answer
Block outgoing identity
                           PRIVATE NO. LED ON when active
Voicemail
Listen to voicemails
                           MESSAGE
                                    + Mailbox + Message List +..
Change Greeting
                           MESSAGE
                                    + Mailbox + Setup Voice Mail
                                    + Intro Message + Record
Remote Access
                          Dial # during voicemail greeting + PIN
```

Magnet Voice


Executive IP Phone



Quick Reference Guide

Magnet Voice

Executive IP Phone



The Magnet Voice Phone is a user-friendly Voice Over IP terminal which can be connected to Magnet Voice PBX over your broadband.

Connecting to Magnet Voice

Connect the LAN port on the underside of the phone to the LAN switch/hub with an Ethernet cable. Plug the DC power supply into the phone and into the mains. The phone also supports power over the Ethernet cable. The phone will power up and automatically register with the Magnet Voice system and display the time, date and user number.

Please consult the Magnet Voice full installation manual. www.magnet.ie/business/support/userguides/

Function keys

MESSAGE for voice mails and missed calls


MUTE disconnects microphone for offline consultation

REDIAL for any of the last 30 numbers

PARK a call for pick-up elsewhere or UNPARK

FORWARD to divert calls

HOLD to place a call on hold or retrieve a call



Login to your personal Magnet Voice Phone Portal

You can easily manage your Magnet Voice Phone settings, personal phonebook, call diversions and voicemails by logging into Magnet Voice Online from your browser.

Contact the Magnet Voice Online system administrator to receive your Username and PIN.