

Make a call	
Handset	Lift Handset + Internal Number Lift Handset + 9 + External Number
Speaker	+ Internal Number or + 9 + External Number
Headset	+ Internal Number or + 9 + External Number
Predial	Internet Number + Send or 9 + External Number + Send
Directory	Phone Bk + Personal Addr Book +
Call Lists	PBX + List of calls +
Redial	REDIAL

Make a second Call while on a call	HOLD + Internal Number or HOLD + 9 + External Number
------------------------------------	--

Conference	During a second call press CONFERENCE
------------	---------------------------------------

Answer a call	
Handset	Lift Handset
Speaker	or Answer
Headset	or Answer
answer a second call	Answer

Handle a Call	
Hold/Retrieve	HOLD
Transfer	TRAN + Number + Hangup
Park/Unpark	PARK

Forward	
Forward All Calls/ Clear Forward	Forward softkey to be activated
Forward on busy	PBX + Call Forward + Forward on busy
Forward no Answer	PBX + Call Forward + Forward no Answer

Block Outgoing Identity	No Button on default
-------------------------	----------------------

Voicemail	
Listen to voicemails	VOICEMAIL + Mailbox + Message List + ...
Change Greeting	MESSAGE
Remote Access	Dial # during voicemail greeting + PIN



Magnet Voice


Yealink T42G phone



Quick Reference Guide

Magnet Voice

Yealink T42G phone




Item	Description	
⑤ Speakerphone Key	Toggles and indicates the hands-free speakerphone mode.	
⑥ Volume Key	Adjusts the volume of the handset, headset, speaker or ringer.	
⑦ Keypad	Provides the digits, letters, and special characters in context-sensitive applications.	
⑧		Scroll through the displayed information.
		Confirms actions or answers incoming calls.
		Cancels actions or rejects incoming calls.
⑨ Soft Keys	Label automatically to identify their context-sensitive features.	
⑩ Speaker	Provides hands-free (speakerphone) audio output.	
⑪ Hookswitch Tab	Secures the handset in the handset cradle when the IP phone is mounted vertically. For more information on how to adjust the hookswitch tab, refer to Yealink Wall Mount Quick Installation Guide for Yealink IP Phones .	
⑫ Hookswitch	<ul style="list-style-type: none"> Picking up the handset from the handset cradle, the hookswitch bounces and the phone connects to the line. Laying the handset down on the handset cradle, the 	

Item	Description	
① LCD Screen	Shows information about calls, messages, soft keys, time, date and other relevant data: <ul style="list-style-type: none"> Default account Call information — caller ID, call duration Icons, PBX, Phone Bk, Park, Voicemail, etc Missed call text or second incoming caller information Prompt text (for example, "Saving config file!") Time and date 	
② Power Indicator LED	Indicates phone power and some feature statuses. <ul style="list-style-type: none"> Receives an incoming call — Fast flashing Receives a voice mail or text message — Slowly flashing 	
③ Line Keys	Use these keys to activate up to twelve accounts and assign various features.	
④	(Mute Key)	Toggles and indicates mute feature.
	(Headset Key)	Toggles and indicates the headset mode.
	(Message Key)	Accesses voice mails.
	(Redial Key)	Redials a previously dialed number.

Connecting to Magnet Voice

Connect the LAN port on the underside of the phone to the LAN switch/hub with an Ethernet cable. Plug the DC power Supply into the phone and into the mains. The phone also supports power over the Ethernet Cable. The phone will power up and automatically register with the Magnet voice System and display the time, date and user number.

Please consult the Magnet Voice full installation manual.
www.magnet.ie/business/support/userguides



Login to your personal Magnet Voice Phone portal

you can easily manage your Magnet Voice Phone settings, personal phonebook, call diversions and voicemails by logging into Magnet Voice Online from your browser.

Contact the Magnet Voice Online system administrator to receive your Username and PIN