Directory Phone Bk + Personal Addr Book +

Call Lists PBX + List of calls +

Redial REDIAL

Make a second Call HOLD + Internal Number or HOLD + 9 +

while on a call External Number

Conference During a second call press CONFERENCE

Answer a call

Handset
Speaker
Headset

Headset

Answer

Answer

Answer

Handle a Call

Hold/Retrieve HOLI

Transfer TRAN + Number + Hangup

Park/Unpark PARK

Switch between calls Press Swap Button

Forward

Forward All Calls/ Clear Forward

Forward Softkey to be activated

Forward on busy Forward no Answer

PBX + Call Forward + Forward on busy
PBX + Call Forward + Forward no Answer

Block Outgoing Identity

PRIVATE NO. LED ON when active

Voicemail

Listen to voicemails VOICEMAIL + Mailbox + Message List + ...
Change Greeting MESSAGE

Remote Access Dial # during voicemail greeting + PIN



Magnet Voice

Yealink T46g phone


VOICE - BROADBAND - WI-FI



Quick Reference Guide

Magnet Voice

Yealink T46g phone



	ltem	Description
1	LCD Screen	Shows information about calls, messages, soft keys, time, date
		and other relevant data:
		Default account
		Call information—caller ID, call duration
		Icons, displays park, voicemail, PBX, Phone Bk etc.
		Missed call text or second incoming caller information
		Prompt text (for example, "Saving config file!")
		Time and date
2	Power Indicat or LED	Indicates phone power and some feature statuses.
		Receives an incoming call — Fast flashing
		Receives a voice mail or text message — Slowly flashing
3	Line Keys	Use these keys to activate up to sixteen accounts and assign
		various features.
4	HEADSET Key	Toggles and indicates the headset mode.
	MUTE Key	Toggles and indicates mute feature .
(5)	MESSAGE Key	Accesses voice messages .
	HOLD Key	Places a call on hold or resumes a held call.
	REDIAL Key	Redials a previously dialed number.
	TRANSFER Key	Transfers a call to another party.

	Item	Description
6	Speakerphone Key	Toggles and indicates the hands-free speakerphone mode.
7	Volume Key	Adjusts the volume of the handset, headset, speaker , ringer or media.
8	Keypad	Provides the digits, letters and special characters in context-sensitive applications.
9	$\odot \odot \odot \odot$	Scroll through the displayed information.
	ОК	Confirms actions or answers incoming calls.
	*	Cancels actions or rejects incoming calls.
10	Soft Keys	Label automatically to identify their context -sensitive features.
11)	Speaker	Provides hands -free (speakerphone) audio output.
(12)	Hookswitch Tab	Secures the handset in the handset cradle when the IP phone is mounted vertically. For more information on how to adjust the hookswitch tab, refer to Yealink Wall Mount Quick Installation Guide for Yealink IP Phones.
13)	Hookswitch	Picking up the handset from the handset cradle, the hookswitch bounces and the phone connects to the line,


Connecting to Magnet Voice

Connect the LAN port on the underside of the phone to the LAN switch/hub with an Ethernet cable. Plug the DC power Supply into the phone and into the mains. The phone also supports power over the Ethernet Cable. The phone will power up and automatically register with the Magnet voice System and display the time, date and user number.

Please consult the Magnet Voice full installation manual. www.magnet.ie/business/support/userguides







Login to your personal Magnet Voice Phone portal

You can easily manage your Magnet Voice Phone settings, personal phonebook, call diversions and voicemails by logging into Magnet Voice Online from your browser.

Contact the Magnet Voice Online system administrator to receive your Username and PIN